



## FiberLink 3353 Series



**3G/HD/SD-SDI to HDMI® Optical  
Receiver**

**Installation and Operations  
Manual**

Contents

Welcome ..... 3

Features ..... 3

Package Contents..... 3

Technical Specifications

    Model Part Number Specifications ..... 4

    General Specifications..... 4

Installation Instructions ..... 6

Audio Pair Selection..... 7

Indicator LEDs ..... 7

Application Diagrams ..... 8

Operating Pointers..... 9

Troubleshooting ..... 9

Maintenance and Repairs ..... 10

Certifications ..... 10

## Welcome

Thank you for purchasing Artel Video Systems' FiberLink 3353 Series. The 3353 Series is used to convert 3G/HD/SD-SDI with or without embedded audio transmitted over a single fiber optic core to HDMI®. The Fiberlink 3353 Series is compatible with single mode or multi-mode fiber. The 3353 is also compliant with SMPTE 297-2006 for seamless interoperability with other SMPTE 297-2006 devices. The system delivers noise-free transmission that retains all of the signals' initial parameters, regardless of fiber optic cable attenuation. The 3353 Series also provides immunity to video pathological signals over the entire link budget and operating temperature range.

## Features

- Convert 3G/HD/SD-SDI with embedded audio to HDMI® with audio pair selection
- Supports all SD and HD resolutions to 1080p/60
- Fully SMPTE 297-2006 compliant fiber input
- HDMI® embedded and stereo line level outputs (if audio present in SDI stream)
- Re-clocked SDI BNC output allows for continuous 3G/HD/SD-SDI signal distribution
- User selection from up to 8 audio channel pairs for multilingual or multimessage support
- Automatic selection of output resolution - no scaling
- ST and LC fiber connector options
- Small compact design
- Compatible with Fiberlink 3350, 3360 & 3380 Series, Fiberlink Matrix and Scan Do® HD's optical output.

## Package Contents

- One FiberLink 3353
- This User's Manual

## Technical Specifications

### Model Part Number Specification

Unit Type	Part Number
Receiver Box	3353-B7L (LC) 3353-B7S (ST)

### General Specifications

Indicators	Power, Alarm, Data Rate Lock (3G, HD, SD)
Box Version Dimensions	6.5 W x 1.15 H x 6 L (inches) 165 W x 29 H x 152 L (mm)
Weight	16 ounces, 453.5 grams
Power	9-24 volts, AC or DC, 5.5 watts, 18.8 BTU/Hr
Operating Temperature	-10° C to +50° C

### Fiber Optic Input

SMPTE 297-2006 Labeling	PC-ABCD-1310-1550
Connector	LC receptacle, PC polish or ST
Wavelength	1100 - 1620 nm
Minimum Input Sensitivity	-17 dBm at 2.97 Gbps; -20 dBm at 1.485 Gbps -23 dBm at 270 Mbps;
Maximum Input Power	0 dBm

### Video Output

Number of Outputs	1
Connector Type	HDMI® Female
Signal Format	Single link HDMI® with embedded audio, RGB or YCrCb as negotiated with display
Resolutions Supported	All 3G/HD/SD-SDI formats from standard definition to 1080p/60
3G/HD/SD-SDI Output	Standard BNC, Follows fiber optic input
HDCP Compliant	Yes. SDI signals, by definition, are not encrypted

## Technical Specifications

### Audio Output

#### Optical Input

Number of Audio Channels	2 channels, unbalanced, line level 2 channels embedded in HDMI® signal
Audio Connector	RCA Jacks
Switches	Front panel selection of one of 8 audio channel pairs on SDI signal to output
NOTE:	Audio on HDMI® and line level are available simultaneously and extracted from audio embedded within SDI signal in accordance with SMPTE standards.

### 3G/HD/SD-SDI Output

Signal Level	800mV $\pm$ 10%
DC Offset	0V $\pm$ 0.5V
Rise/Fall Time	< 135 ps at 2.97 Gbps per SMPTE 424M; < 270 ps at 1.485 Gbps per SMPTE 292; 0.4 ns to 1.5 ns at 270 Mbps per SMPTE 259M
Overshoot	< 10% of amplitude
Timing Jitter	< 0.2 UI at 270 Mbps; < 1.0 UI at 1.485 Gbps; < 2.0 UI at 2.97 Gbps with color bar signal
Alignment Jitter	< 0.2 UI at 270 Mbps; < 0.2 UI at 1.485 Gbps; < 0.3 UI at 2.97 Gbps with color bar signal
Re-clocking	At 270 Mbps, 1.485 Gbps & 2.97 Gbps

## Installation Instructions


The FiberLink 3353 Series of fiber optic transmission systems are ready for immediate use and do not require any special tools. However, an Optical Power Meter, such as the FiberLink 6650, can be useful in determining optical loss budgets during your systems design and maintenance.

FiberLink 3353 will operate with the Fiberlink 3350, Fiberlink 3360, Fiberlink 3370, Fiberlink 3380, Scan Do® HD, Fiberlink Matrix and SMPTE 297-2006 compliant optical transmission units. The following procedure presumes you have followed the instructions for installing your optical transmitter unit.

### The following instructions describe the typical installation procedure:

- 1) Connect the fiber optic cable to the optical input of the receiver unit.
- 2) Connect the video output cable (HDMI®) to the video output HDMI® connector on the receiver unit.
- 3) Optionally connect any audio cables and using the channel pair rotary selector, choose your desired audio output channel. Audio is also embedded on the HDMI® cable.
- 4) Terminate any unused BNC output connector at 75 Ohms.
- 5) Connect the Universal Power Supply to the transmitter and receiver units. Please refer to figure 1.
- 6) When power is applied, the green POWER LED should illuminate, indicating the presence of operating power. The 3G/HD/SD RATE LED will give an indication as described in the Indicator LED's and Alarm Circuitry section of this manual.
- 7) The system should now be operational.

**Figure 1:**  
**Power Connector**  
**DC Input Polarity**



**DANGER!**

The transmitting element in the FiberLink 3350, 3360, 3370 and 3380 transmitter units contains a solid state Laser Diode located in the optical connector. This device emits invisible infrared electromagnetic radiation which can be harmful to human eyes. The radiation from this optical connector, if viewed at close range with no fiber optic cable connected to the optical connector, may be sufficient intensity to cause instantaneous damage to the retina of the eye. Direct viewing of this radiation should be avoided at all times!

## Audio Pair Selection

The FiberLink 3353 Series has a rotary dial switch that allows you to select which audio pair to output. The chart below describes the operation of the rotary switch positions:

### Rotary Switch Positions

Position	Function
0	Will mute the audio output
1 through 8	Will output the respective audio channel pair on the HDMI® cable and the audio output connectors
9	Not used




## Indicator LEDs

The FiberLink 3353 Series has six integral indicator LEDs that are used to monitor the state of the unit.

### Receiver LEDs

LED	Status	Definition
Power	On	Indicates that correct power has been applied.
3G Rate	Off On	Indicates no 3G-SDI data rate lock Indicates 3G-SDI data rate lock at 2.97 Gbps or 2.97/1.001 Gbps
HD Rate	Off On	Indicates no HD-SDI data rate lock Indicates HD-SDI data rate lock at 1.485 Gbps or 1.485/1.001 Gbps
ED Rate	Off On	Indicates no ED resolution data rate lock Indicates ED resolution data rate lock at 540 Mbps
SD Rate	Off On	Indicates no SD-SDI or DVB-ASI data rate lock Indicates SD-SDI or DVB-ASI data rate lock at 270 Mbps
Alarm	On	Loss of optical signal

*Note: The 3G, HD, ED and SD LEDs indicators are off when a non-standard signal is applied.*





## Operating Pointers

Remember to check attenuation of the fiber optic cable. The system will only operate properly if these specifications fall within the range of the system's loss budget.

## Troubleshooting

Multimode fiber optic cable contains an optical fiber with a light carrying "core" that is only .0025 inches (62.5 microns) in diameter. Single mode fiber optic cable has an even smaller "core," only .00032 to .0004 inches (8-10 microns). This is smaller than a human hair! Therefore, any minute particles of dirt or dust can easily block the fiber from accepting or radiating light. To prevent this from happening, always use the provided dust caps when ever optical connectors are exposed to air. It is also a good idea to gently clean the tip of an optical connector with a lint-free cloth moistened with alcohol whenever dust is suspected.

The status of the LEDs should provide the first clue as to the origin of any operational failure. If these are off, it usually means that the fiber is broken or has too much attenuation. Next, be certain that the input and output signal connections are correct.

An optical power meter, such as the FiberLink 6650, a visible light source, such as the FiberLink 6656, and a Two Wavelength Light Source, such as the FiberLink 6652 or 6654, can greatly assist and expedite troubleshooting of fiber optic transmission systems and are recommended tools all installers should have available.

Finally, although multimode and single mode devices may look the same, they will not operate properly together. Using the wrong device or fiber can easily add more attenuation than specified, resulting in poor overall performance. It should be noted that some of our fiber optic products support both single mode and multimode fiber in the same unit.

If, after reviewing the above possibilities, the system is still not operating, please contact the Customer Service Department for further assistance. If you suspect your problem is caused by the optics or the fiber optic cable, and you have an optical power meter, please take the appropriate measurements prior to contacting support.

## Maintenance and Repairs

The FiberLink 3353 Series has been manufactured using the latest semiconductor devices and techniques that electronic technology has to offer. They have been designed for long, reliable and trouble-free service and are not normally field repairable.

Should difficulty be encountered, Artel Video Systems maintains a complete service facility to render accurate, timely and reliable service of all products.

The only maintenance that can be provided by the user is to ascertain that optical connectors are free of dust or dirt that could interfere with light transmission and that electrical connections are secure and accurate. Please see the Troubleshooting section of this manual for additional information.

All other questions or comments should be directed to our Customer Service Department. It should be noted that many "problems" can easily be solved by a simple telephone call.

If you suspect your problem is caused by the optics or the fiber optic cable, and you have an optical power meter, please take the appropriate measurements prior to contacting support.

---

### Certifications





- Artel Video Systems Corp.**  
5B Lyberty Way,  
Westford, MA 01886 USA  
T: 978-263-5775  
F: 978-263-9755  
sales@artel.com  
customercare@artel.com  
www.artel.com

